PrintPartner 12V PAGE PRINTER PARTS CATALOGUE

FUJITSU LIMITED

Communications and Electronics

Tokyo, Japan

This is parts catalogue for PrintPartner 12V Page Printer.

This manual is for service engineers.

There are several models of PrintPartner 12V Page Printer.

This manual covers all models.

This manual consists of two parts: Parts List and Parts Drawings. Parts list has layer structure. You can find assembly levels. Parts drawing does not have the layer structure. You can see the model difference from the parts list easily.

There are other manuals for service engineers as follows. Especially the maintenance manual has close relationship to this manual.

PrintPartner 12V Page Printer Maintenance Manual

PrintPartner 12V Page Printer Schematic Diagrams

PrintPartner 12V Page Printer User's Manual

PrintPartner 12V Page Printer Product Description

		REVISION RECORD
Edition	Date published	Revised contents
01	March 1998	First issue
	Specif	ication No. C145-GO21-01EN

The contents of this manual may be revised without prior notice.

All Rights Reserved, Copyright© 1998 FUJITSU LIMITED. Printed in Japan. No part of this manual may be reproduced in any form without permission.

Address your comments and inquiries on this manual to:

FUJITSU COMPUTER PRODUCTS OF AMERICA, INC.

2904 Orchard Parkway, San Jose

CA 95 134-2022, U.S.A. TEL: (1-408) 432-6333 FAX: (1-408) 894- 1709

FUJITSU CANADA INC.

2800 Matheson Boulevard East

Mississauga, Ontario L4W 4X5, CANADA

TEL: (1-905) 602-5454 FAX: (1-905) 602-5457

FUJITSU AUSTRALIA LIMITED

475 Victoria Avenue, Chatswood N.S.W., 2067, AUSTRALIA

TEL: (6 1-2) 410-4555 FAX: (6 1-2) 411-8603

FUJITSU DEUTSCHLAND GmbH.

Frankfurter Ring 211

80807 Munchen, GERMANY

TEL: (49-89) 32378-O FAX: (49-89) 32378- 100

FUJITSU ESPANA, S.A.

Almagro 40,28009 Madrid, SPAIN

TEL: (34-1) 581-8400 FAX: (34-1) 581-8125

FUJITSU EUROPE LTD.

2 Longwalk Road, Stockly Park, Uxbridge Middlesex UB11 1AB, ENGLAND

TEL: (44-8 1) 573-4444 FAX: (44-8 1) 573-2643

FUJITSU FRANCE S.A.

1, place des Etats-Unis Silic 310 94588 RUNGIS Cedex, FRANCE

TEL: (33- 1) 41-80-38-80 FAX: (33- 1) 41-80-38-66

FUJITSU HONG KONG LIMITED

Room 2521, Sun Hung Kai Centre 30 Harbour Road, HONG KONG

TEL: (852) 827-5780 FAX: (852) 827-4724

FUJITSU ICIM LTD.

Nagar Road, Pune 411 014, INDIA

TEL: (9 1-212) 681-528 FAX: (9 1-2 12) 680-238

FUJITSU ITALIA S.p.A.

Via Nazario Sauro, 38

20099 Sesto S, Giovanni (MI), ITALY

TEL: (39-2) 26294-1 FAX: (39-2) 26294-201

FUJITSU KOREA LTD.

9th Floor, Korean Reinsurance Bldg. 80, Susong-Dong, Chongro-Gu Seoul Special City, KOREA

TEL: (82-2) 739-3281 FAX: (82-2) 739-3294

FUJITSU NORDIC AB

Kung Hans Väg 12

S-191 76 Sollentuna, SWEDEN

TEL: (46-8) 626-6000 FAX: (46-8) 626-6711

FUJITSU (SINGAPORE) PTE. LTD.

75 Science Park Drive

#02-06 CINTECH II, SINGAPORE 0511

TEL: (65) 777-6577 FAX: (65) 777-8794

FUJITSU SYSTEMS BUSINESS

(MALAYSIA) SDN. BHD.

Fujitsu Plaza, 1A, Jalan Tandang 204 P.O. Box 636 Pejabat Pos Jalan Sultan

46770 Petaling Jaya

Selangor Darul Ehsan, MALAYSIA

TEL: (60-3) 793-3888 FAX: (60-3) 793-0888

FUJITSU SYSTEMS BUSINESS

(THAILAND) LTD.

12th Floor, Olympia Thai Tower 444 Rachadapisek Road, Samsennok Huaykwang, Bangkok 103 10, THAILAND

TEL: (662) 512-6066 FAX: (662) 512-6068

FUJITSU TAIWAN LTD.

8th FL., NO. 170, Hung Tai Center Tun Hwa N. RD., Taipei, TAIWAN

TEL: (886-2) 545-7700 FAX: (886-2) 717-4644

FUJITSU LIMITED

Computer Products Business Group Kamikodanaka 4-l-1, Nakahara-ku

Kawasaki-shi 211, JAPAN TEL: (8 1-44) 754-8633 FAX: (8 1-44) 754-8510

1. HOW TO REFER TO THIS MANUAL

Example:

Index No.	Compositi & Quanti	_	S P	Specification	Parts name (Description) ⑦	PP1		Remarks
3 1~8 1~5 1 2 3 4 5 6 7 8 9	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	0 * 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	CA04291-B300 CA04291-B301 CA04291-B302 CA04291-B303 CA04291-B350 CA04291-B351 CA04291-B352 CA04291-B353 CA04291-B354 CA04040-F550 CA04040-G550 CA04040-G550 CA04040-G585 CA02758-Y803 CA02758-Y805 CA02758-Y807 CA04040-O574 CA04040-V573 F6-SBD3-06121	PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V (CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) UPPER COVER ASY U COVER SUB ASY U COVER SUB ASY UPPER DOOR UD GUIDE L UD GUIDE L UD GUIDE R UD GUIDE LL OP PANEL OP CABLE VOLUME CABLE SCREW	0000 0000000000	240 000000 0000000000	N-AMERICA FCI FCPA ASIA EUROPE FAL ASIA EUROPE NO-BRAND EUROPE

- 1 This figure shows the index number of the part in the drawing.
- These columns show the construction levels. A higher level part consists of the following lower level parts listed until the quantity of the next part appears at the same level. See example 3.
- 3 m-n shows an assembly or unit consisting of more than one part. The upper cover subassembly consists of a cover subassembly, an upper door, and guides.
- 4 These parts are at the same level and belong to the same upper level part.
- 5 Parts with an asterisk (*) are recommended spair parts.
- 6 The upper cover assembly is the part name of item numbers 1 to 5.
- 7 PP12V stands for PrintPartner 12V.
- 8 Part with an at can be purchased.
- * The upper cover assembly is a recommended spare part.

2. SPECIFICATONS

The table below lists standard models of the PrintPartner 12V printer.


No.	Specificatins	Logo	PP	212V	Remarks
			120	220-240	
1	CA04291-B300	PrintPartner 12V	0		N-AMERICA LETTER
2	CA04291-B301	PrintPartner 12V	0		FCI LETTER
3	CA04291-B302	PrintPartner 12V	0		FCPA LETTER
4	CA04291-B303	PrintPartner 12V	0		ASIA A4
5	CA04291-B3 5 0	PrintPartner 12V		0	EUROPE A4+MANUAL
6	CA04291-B351	PrintPartner 12V		0	FAL A4
7	CA04291-B3 52	PrintPartner 12V		0	ASIA A4
8	CA04291-B353	PrintPartner 12V		0	EUROPE (*) A4
9	CA04291-B360			0	NO BRAND A4
10	CA04291-B354	PrintPartner 12V		0	EUROPE DROP-SHIP
11					
12					
13					
14					
15					
16	•				
17					
18					
19					
20					<u>-</u>

^{*} The user's manual and power cord are not packed with the printer.


They are attached at the sales companies.


3.PARTS LIST AND PARTS DRAWING OF PRINTER MECHANISM

3.1 Visual Index of Parts



3.2 Upper Cover






3.2 Upper Cover

Index	1	-	tion			S	Specification	Parts name	PP	12 V	Remarks
No.	ă '	y uan	tity					(Description)	120		
	1 1 1 1 1 1 1 1						CA04291-B300 CA04291-B301 CA04291-B302 CA04291-B303 CA04291-B350 CA04291-B351 CA04291-B352 CA04291-B353 CA04291-B353 CA04291-B354	PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V (CENTRO-120V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V) PP12V(CENTRO-220~240V)	0000	~240	N-AMERICA FCI FCPA ASIA EUROPE FAL ASIA EUROPE NO-BRAND EUROPE
1~8 1~5 1 2 3 4 5 6 7 8			1	1 1 1 3	1 1 2 1	*@@@@*@@@	CA04040-F550 CA04040-G550 CA04040-G585 CA02758-G803 CA02758-Y805 CA02758-Y806 CA02758-Y807 CA04040-0574 CA04040-Y564 CA04040-Y573 F6-SBD3-06121	UPPER COVER ASY U COVER SUB ASY COVER SUB ASY UPPER DOOR UD GUIDE L UD GUIDE R UD GUIDE LL OP PANEL OP CABLE VOLUME CABLE SCREW	00000000000	00000000000	
		1 1 1 1 1					CA04291-K300 CA04291-K301 CA04291-K302 CA04291-K303 CA04291-K350 CA04291-K351 CA04291-K352 CA04291-K353 CA04291-K353	ACCESSORY	000	000000	N-AMERICA FCI FCPA ASIA EUROPE FAL ASIA EUROPE NO-BRAND EUROPE
10 11 12 13			1 1 1 1 1 1 1			00000000	CA02758-G461 C145-E228-01EN CA40782-E910 CA02417-Y720 CA02417-Y724 CA02417-Y725 CA02758-0990 CA98001-3771 CA98001-4430	CL BLUSH ASY USER'S MANUAL SOFTWARE SET SIZE LABEL A4 SIZE LABEL LETTER SIZE LABEL EXECUTIVE AC CORD SET AC CORD SET (3M) AC CORD SET (2M)	000000	000000 00	PAPER TRA PAPER TRA PAPER TRA 100-120V 220-240V 220-240V
15		1					CA04291-Y851	LOGO LABEL	0	0	


3.3 Printer



3.3 Printer

	Composition & Quantity	1	Specification	Parts name (Description)	PP1	i	Remarks
	a Quantity	"		(Description)	120	220 ~240	
1~14	1 1 1 1 1		CA04291-C300 CA04291-C303 CA04291-C350	PRINTER PRINTER PRINTER	00	~24U	120V 120V A4 220-240V
1	1		CA04291-E300	PRINTER M UNIT	0	0	
2 3 4 5~6 5 6	1 1 1 1 1 1	0000	CA02758-Y812 CA02758-Y814 F6-SBD3-06121 CA02758-F815 CA02758-G818 CA02758-Y816	SIDE COVER R BACK COVER SCREW STACKER UNIT STACKER ASY REAR GUIDE	000000	000000	No.7 deleted
8 9	1 1	@	CA02758-G811 CA02758-Y813	SIDE COVER L FRONT COVER	00	0	No.7 deleted
10							No.10 deleted
11	1 1		CA02758-F701 CA02758-F702	PAPER TRAY PAPER TRAY	00	00	A4 LETTER
12	1 1		CA04040-F571 CA04040-F572	POWER UNIT POWER UNIT	0	0	120V 220-240V
13	1 1		CA04040-F102	BASE FRAME ASY	0	0	
14			CA02758-G122	LD STAY ASY	0	0	
	9		F6-SW2N3-08111	SCREW		0	
15	1	@	CA02758-0126	OZONE FLITER	0	0	


3.4 Printer Mecha Unit 1



3.4 Printer Mecha Unit 1

			tion tity	:	S	Specification	Parts name	PP	2٧	Remarks
	a (vuan	LITY		۲		(Description)		220	
1~8		1				CA02758-G143	HV UNIT	0	~240 O	
1 2 3 4 5 6 7 8		4	1 1 1 3 1 5		000 * 0 * 00	CA02758-Y145 CA02758-Y651 CA02758-Y144 CA02951-4292 CA02758-0195 CA02758-0195 F6-SW2N3-08111	BOARD COVER SENSOR LEVER 1 HV GUIDE HV BOARD TAPPING SCREW MECHA BOARD TAPPING SCREW SCREW	00000000	00000000	
9 10 11 12 13 14 15 15-1 16 17 18 19 20		1 1 2 1 1 1 1 2 3 3 1 5			0 * 0 * 0 0 0 0 0 0 * 0 0	D860-1173-X826 CA04040-G572 CA02758-0195 CA02758-0195 CA02758-0195 CA04040-Y568 CA02758-Y122 CA98001-8943 CA04040-Y556 F6-SW2N3-06121 CA04291-J300 F6-SW2N3-08121 CA04040-F569	KNOB VOLUME BOARD TAPPING SCREW MFF BOARD TAPPING SCREW MFF CABLE LD CABLE FELIGHT CORE METAL FITTING SCREW ROM BOARD (PC BOARD) SCREW CABLE ASY	0000000000000	0000000000000	
21~ 23 21 22 23 24 25		1 1 1	1 1 1		*	CA02758-F696 CA02758-G696 CA02758-Y696 CA02758-Y697 CA02758-Y698 F6-SN2TP3-06	SFS ASY SFS BOARD ASY SFS LEVER SFS COVER SFS CABLE TAPPING SCREW	000000	000000	
26 27 28 29 30 31 32 33 34 35 36 37		1 3 1 2 1 2 2 1 1 1 1			0000000000000000	CA04040-G613 F6-SW2N3-08111 CA04040-Y552 F6-SBD3-06121 CA04040-G618 F6-SBD3-06121 F6-SW2N3-06121 F3RH11.8-15-7.3 CA98001-0829 CA04040-Y615 F6-SW2N3-06121 CA04040-Y580	SHIELD ASY SCREW SHADE PLATE B SCREW BACK COVER ASY SCREW SCREW FELIGHT CORE(FERRICO) CABLE CLAMP SIMM COVER 3 SCREW FG SPRING PLATE	000000000000	000000000000	
38~ 39 38 39 40		1 2	1		@ @ @	CA02758-G817 CA02758-Y817 CA02758-G360 F6-SN2TP3-06	FRONT FRAME ASY FRONT FRAME TS ASY TAPPING SCREW	0000	0000	
41 42 43		1	1			CA02758-Y024 CA02758-0196 CA02946-G152	RF PLATE TAPPING SCREW GUIDE PLATE ASY	000	000	


3.5 Printer Mecha Unit 2-l



3.5 Printer Mecha Unit 2-1

	Composi & Quan			S	Specification	Parts name (Description)	PP1	12 V	Remarks
	d dan	1				(Description)	120	220 ~240	
1~ 17	1	1			CA02758-F114 CA02758-G111	FRAME L ASY FRAME L SUB ASY	00	00	
2~ 4 2 3 4 5 6 7 8 9 10 11		3 1 1 1 1 1 1	1 2 1	* @	CA04291-F201 CA02758-0201 F6-SW2N3-08111 CA02758-G202 CA02758-Y204 CA02758-Y204 CA02758-Y212 CA02758-Y212 CA02758-Y213 CA02758-Y214 CA02758-Y215 CA02758-Y209	P MOTOR ASY PICK MOTOR SCREW PM BRACKET ASY TAPPING SCREW GEAR P MFF GEAR A ASY MFF GEAR B MFF GEAR C MFF GEAR D MFF GEAR E MFF GEAR BRACKET	000000000000	000000000000	
13~ 16 13 14 15 16 17		1	1 1 1 1	@	CA02758-G821 CA02758-Y821 CA02758-Y825 CA02758-Y216 CA02758-Z821 F6-ER4-S	PT GUIDE L ASY PT GUIDE L RUBBER FOOT MFF RUBBER PTGR DUMPER SNAP RING	000000	000000	
18	2				F6-SN2TP4-10	TAPPING SCREW	0	0	:
19 20 21 22	1 3 1 3				CA02758-Y105 F6-SW2N3-08111 CA02758-Y106 F6-SW2N3-08111	L TYPE STAY SCREW LOWER STAY SCREW	0000	0000	
23 24	1 2				CA02758-Y104 CA02758-0195	STAY F TAPPING SCREW	00	00	
25~ 27 25 26 27	1	1		*	CA02758-G119 CA02758-Y114 CA02758-Z114 CA02758-G127	PR GUIDE L ASY PR GUIDE L PRGL LABEL COVER OPEN SW	0000	0000	
28 29	1 1			@	CA02758-Y606 CA02758-0195	FG PLATE P TAPPING SCREW	00	00	


3.5 Printer Mecha Unit 2-2



3.5 Printer Mecha Unit 2-2

	Composit		S	Specification	Parts name (Description)	PP	12 V	Remarks	
	u qualit	,			(Description)		220 ~240		
1 2 3	1 1 8			CA02758-G261 CA02758-G112 CA02758-0195	GEAR BOX ASY FRAME R SUB ASY TAPPING SCREW	000	000		
4~ 11 4 5 6 7 8 9 10 11	1	1 1 1 1 1 1 1 1	* 0 * 0 0 0	CA02758-G823 CA02758-Y823 CA02758-Y825 CA02758-G182 F6-SN2TP3-08 CA02758-Y164 CA02758-Y727 CA02758-Y728 CA02758-Z823	PT GUIDE R ASYL PT GUIDE R RUBBER FOOT PSS BOARD TAPPING SCREW PSS CABLE PT LOCK LEVER PT LOCK SPRING PTGL DUMPER	000000000	000000000		
12~ 18 12 13 14 15 16 17 18	1	1 4 1 4 1 1 1	* 90999	CA02758-F252 CA02758-0251 CA02758-Y291 CA02758-G252 CA02758-0195 CA02758-Y256 CA02758-Y257 CA02758-Y255 CA02758-O195	M MOTOR ASY MAIN MOTOR DUMPER MM MM BRACKET ASY TAPPING SCREW GEAR MA GEAR MB MM CABLE TAPPING SCREW	000000000	000000000		
20	1		*	CA02758-0129	FAN	0	0		
21~ 23 21 22 23	1	1 1 1	@	CA02758-G115 CA02758-Y115 CA02758-Z115 CA02758-Y116	PR GUIDE R ASY PR GUIDE R PRGL LABEL DRFG	0000	0000		


3.6 Base Frame



3.6 Base Frame


	1	posi Quan		S	Specification	Parts name (Description)	PP	12 V	Remarks
	a	yuari	. 1 L y			(Description)	120	220	
1~ 37 1 2, 3, 10, 11) 2 3 4 5 6 7 8 9 10 11 12 13 14 15	1	1 1 1 1 1 1 2 2 2 1 1 1 1 1 1 1 1 2 2 2		* @@@@@@@*	CA04040-F102 CA02758-G101 CA02758-G612 CA02758-G611 CA02758-Y613 CA02758-Y605 CA02758-G615 CA02758-G615 CA02758-G617 CA02758-G687 CA02758-Y623 CA02758-Y623 CA02758-Z011 CA02758-Z011 CA02758-Z012 CA02758-Y458 CA02758-F474 CA04040-G690 CA02758-0195	BASE FRAME ASY BASE FRAME ASY FEED ROLLER ASY FEED ROLLER ASY GEAR F BEARING PF FG PLATE ASY REGIST ROLLER LEVER ASY BEARING R SPRING R SHEET RE1 SHEET RE2 FG PLATE T TRCG UNIT PAPER GUIDE F ASY TAPPING SCREW	000000000000000000	~240	
16~ 19 16 17 18 19		1	1 1 2 1	@	CA02758-F221 CA04040-0201 CA02758-G222 F6-SW2N3-08111 CA02758-Y224	R MOTOR ASY REGIST MOTOR RM BRACKET ASY SCREW GEAR R	00000	00000	
20 21 22 23		1 1 1 2		@ * @	CA02758-G604 CA02758-0603 CA02758-G602 CA02758-Y605	SHAFT P ASY PICK GEAR ROLLER P ASY BEARING PF	0000	0000	
24 25 26 27 28 29		1 1 1 1 1		000000	CA02758-Y642 CA02758-Y643 CA02758-Y644 CA02758-Y641 F6-WM3-111 F6-SN2TP3-06	RACK GUIDE FL GUIDE FR PINION WASHER TAPPING SCREW	000000	000000	
30 31 32		1 1 1 1 2 1 1		00	CA02758-Y654 CA02758-Y729 CA02758-Y152 CA02758-Y153 CA02758-Y154 CA02758-Y155 CA02758-Y025	SENSOR LEVER 4 TRIDENT LEVER SPRING HV1 SPRING HV2 SPRING HV3 SPRING HV4 TRCG STOPPER	0000000	0000000	
34 35		1			CA02758-Y193 CA02758-Y194	P GUIDE FG L P GUIDE FG R	00	00	
36		2		@	CA02758-Y477	TRCG STOPPER	0	0	
37		3			CA02758-0195	TAPPING SCREW	0	0	

3.7 Laser Diode Stay




3.7 Laser Diode Stay

				iposi Quan				S	Specificat	ion		arts name		PP	12 V	Remarks	
			å	vuan	τιτ			P				escription)	120	220		
	1~	17 1 2 3 4	1	1 1 1 3				* @ @	CA02758-G12 CA02758-Y12 CA04280-E00 CA02758-Y00 F6-SW2N3-08	21 01 63	LD OPT	STAY ASY STAY ICAL UNIT FG COVER EW		00000	~240		
1 1 1	5~ 7~ 8~	7 9 8 9	·	1	1 1 2	1 1 1	√∏ NU	@ *	CA02758-G12 CA02758-012 CA02758-Y12 CA02758-F68 CA02758-Y68 CA02758-Y68 CA02758-Y68	23 24 30 30 33	DCH LED FRA PAP FEE FEE	LED UNIT LED HOLDER ME 2 ASY ER FRAME 2 D A ASY D SPRING A CH ROLLER		00000000	00000000		
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	8 9 9 9 9 9	CAO CAO CAO CAO CAO CAO	2758 2758 2758 2758 2758 8001 2758 2758	-F69 -Y69 -G69 -Y68 -555 -Y68 -Y59 -Y59	0 2 4 5 2 8	GUIC ROLL GEAR GEAR TIMI GEAR LABE	ER G ER A R 6 R 7 A NG B R COV	SUIDI NSY NSY SELT		00000000	000000000	CAUTION CAUTION					10~ 11 10 11 12 13 14 15 16 17



3.8 Power Unit


	Compos & Quai				S P	Specification	Parts name (Description)	PP1	2 V	Remarks
	& y uai	ntity			P		(Description)	120	220 ~240	
1~ 27 1 2 3 4	1 1 1 1 1 5 1				* * @ @	CA04040-F571 CA04040-F572 CA02758-G135 CA02951-4260 CA02951-4265 CA02758-0197 F6-SW2N3-06121	POWER UNIT POWER UNIT PB COVER ASY POWER BOARD POWER BOARD TAPPING SCREW SCREW	0 00 00	00 000	120V 220-240V 120V 220-240V
5 6 7 18 7 8 9 10 11 15 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27	1 3 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 2 1 1	1 1	© © © © © © © © © © © © © © © © © © ©	CA02758-Y137 CA02758-Y655 CA02758-Y675 CA02758-Y675 CA02758-Y679 CA02758-Y676 CA02758-Y670 CA02758-Y670 CA02758-Y672 CA02758-Y672 CA02758-Y671 CA02758-Y671 CA02758-Y671 CA02758-Y677 F6-SN2TP3-08 CA02758-Y661 CA02758-Y662 CA02758-Y663 CA02758-Y668 CA02758-Y668 CA02758-Y668 CA02758-O195	SWITCH COVER SENSOR LEVER 5 PAPER FRAME ASY PAPER FRAME 1 SENSOR LEVER 6 ROLLER ASY SIDE FRAME LP PAPER GUIDE ASY PAPER GUIDE FEED 1 ASY FEED SPRING 1 PINCH ROLLER STACK LEVER P LABEL SIDE FRAME RP TAPPING SCREW SWITCH ASY GEAR 1 GEAR 2 GEAR 3 GEAR 4 GEAR 5 FAN BRACKET FAN ASY SCREW TAPPING SCREW	000000000000000000000000000000000000000	000000000000000000000000000000000000000	



3.9 Heat Roller Unit

	Composi & Quan			S	Specification	Parts name (Description)	PP	12 V	Remarks
	a quan	,		'		(Description)	120	220 ~240	
1~ 38 1~ 26 1~ 18 1 2 3 4 5 6 6-2 7 8	1 1 1	1 1 2 2 1 1 1 1 1 2 2			CA02758-F511 CA02758-F512 CA02758-G504 CA02758-G505 CA02758-G514 CA02758-G519 CA04040-G515 CA02758-E531 CA02758-E511 CA04040-E512 CA02758-F512 CA02758-F532 CA02758-F533	HR UNIT HR UNIT HR SUB UNIT HR SUB UNIT HR BASE UNIT HR FRAME ASY 1 BU ROLLER ASY BEARING BR BEARING HEAT ROLLER HR BEARING HR BEARING ASY GEAR HR RING HR	0 0 0000000000	0 00000000000	120V 220-240V 120V 220-240V
9 10 11 12 13 14~ 16 14 15 16 17 18		2 1 2 1 1 1 1	1 5 5		CA02758-Y544 CA02758-Y541 CA02758-0195 CA02758-0543 CA02758-0199 CA02758-G563 CA02758-Y563 CA02758-Y561 CA02758-Y562 CA02758-O195 CA04040-Y678	SPRING BR HR FRAME U TAPPING SCREW THERMISTOR ASY TAPPING SCREW SEPARATOR ASY PLATE SP SEPARATOR SPRING SP TAPPING SCREW INSULATOR	00000000000	00000000000	
19 20 21 22 23 24 25 26		1 1 1 1 1 1 1 2 1 2			CA02758-Y571 CA02758-Y538 CA02758-Y539 CA02758-0511 CA02758-0512 CA02758-Y577 CA02758-0195 CA02758-G570 CA02758-0195	HR COVER R GEAR HG1 GEAR HG2 HALOGEN LAMP HALOGEN LAMP HR COVER SR TAPPING SCREW COVER SL ASY TAPPING SCREW	0000 0000	000 00000	120V 220-240V
27~ 28 27 28 29 30 31 32 33 34	1 1 2 2 1 1 1	1 1	1 7	3	CA02758-G581 CA02758-Y581 CA02758-0582 CA02758-0584 F6-SW2N3-06121 CA02758-0195 CA02758-G579 CA98001-5557 CA02758-Y573-TK	TH HOLDER ASY HOLDER THERMOSTAT ASY HR CABLE ASY SCREW TAPPING SCREW HR COVER F ASY CONNECTOR PAPER GUIDE HR	000000000	000000000	
35 36 37 38	1 2 1 2				CA02758-Z525 CA02758-0195 CA02758-Z526 CA02758-0195	PLATE L TAPPING SCREW PLATE R TAPPING SCREW	0000	0000	


3.10 Paper Tray



3.10 Paper Tray

	Composition & Quantity	S	Specification	Parts name	PP12V		Remarks
& Quantity				(Description)		220	
1~ 13 1 ~8 1 2 3 4 5 6 7 8	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	00000*0	CA02758-F701 CA02758-F702 CA02758-G701 CA02758-Y701 CA02758-Y716 CA02758-Y717 CA02758-Y718 CA02758-G714 CA02758-G714 CA02758-G721 CA02417-Y708	PAPER TRAY PAPER TRAY PT SUB ASY PAPER TRAY PLATE HOLDER L PLATE HOLDER R PH SPRING P PLATE ASY PP SPRING SEPARATOR ASY HOLDER SPRING	00000000000	~240	
9 10 11 12 13 14 15 16 17	1 1 1 1 1 1 1 1 1	99999999	CA02758-Y711 CA02758-Y712 CA02758-Y713 CA02758-Y719 CA02417-Y720 CA02417-Y724 CA02758-Z801 CA02758-Z802 CA02758-Z803 CA02758-Z804	GUIDE L GUIDE R GUIDE E P SIZE LEVER SIZE LABEL SIZE LABEL SOUND PROOF MATERIAL SOUND PROOF MATERIAL SOUND PROOF MATERIAL SOUND PROOF MATERIAL	000000000	0000000000	A4 LETTER
			· .				
			•				

3.11 Print Unit



3.11 Print Unit

	Composition & Quantity				S Specification	Parts name	PP12	.	Remarks
	a y	uantity		P	P	(Description)	120 2	20 240 ———	
1 ~3 1 2 3	1	1 1 2			CA04040-E671 CA02758-F315 CA02758-F400 CA02758-G371	PRINT UNIT DEV. UNIT DRUM UNIT P LOCK ASY	000	240 ——— O O O	
4	1				CA02758-E300	TONER BOTTLE	0	0	
									-